

- Learning how to use interrupts.
- Interfacing to an external bus.
- State machines in a PLD.
- Data handshaking.
- Moving towards a full system.

- Improve on Lab 1
 - ★ Efficient printing of character strings
 - ★ Program Timer 0.
- Interface 7032 PLDs to 16F877.
- one switch attached to PLD input
- four LEDs attached to PLD output.
- 16F877 reads switch inputs, write LEDs
- Four bit counter created inside PLD.
- Value echoed to terminal if switch value changes.

- Need to set interrupt vector.
- Need to return from interrupt.

```

        org      H'000'          ; Reset vector
        goto     Mainline        ; Location of start of program

        org      H'004'          ; Interrupt vector
        goto     IntServ         ; Start of int service routine
Mainline  ....

        ....

        org      H'100'          ; put service routing at 0x100
IntServ  ....                    ; first inst. of service routine
        ....
        ....
        retfie                    ; return from interrupt instr.
```

What Happens During an Interrupt?

1. Interrupts enabled (INTCON, PIE1)
2. Interrupt stimulus (timer/counter overflows)
3. Interrupts disabled (bit 7 - INTCON)
4. Jump to interrupt vector (address 0x4).
5. Jump to interrupt service routine.
6. Complete interrupt service routine.
7. Re-enable interrupts (RETFIE).

PIC16F87X

2.2.2.3 INTCON REGISTER

The INTCON Register is a readable and writable register, which contains various enable and flag bits for the TMR0 register overflow, RB Port change and External RB0/INT pin interrupts.

Note: Interrupt flag bits get set when an interrupt condition occurs, regardless of the state of its corresponding enable bit or the global enable bit, GIE (INTCON<7>). User software should ensure the appropriate interrupt flag bits are clear prior to enabling an interrupt.

REGISTER 2-3: INTCON REGISTER (ADDRESS 0Bh, 8Bh, 10Bh, 18Bh)

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-x
GIE	PEIE	TOIE	INTE	RBIE	TOIF	INTF	RBIF
bit7							bit0
<p>bit 7: GIE: Global Interrupt Enable bit 1 = Enables all un-masked interrupts 0 = Disables all interrupts</p> <p>bit 6: PEIE: Peripheral Interrupt Enable bit 1 = Enables all un-masked peripheral interrupts 0 = Disables all peripheral interrupts</p> <p>bit 5: TOIE: TMR0 Overflow Interrupt Enable bit 1 = Enables the TMR0 interrupt 0 = Disables the TMR0 interrupt</p> <p>bit 4: INTE: RB0/INT External Interrupt Enable bit 1 = Enables the RB0/INT external interrupt 0 = Disables the RB0/INT external interrupt</p> <p>bit 3: RBIE: RB Port Change Interrupt Enable bit 1 = Enables the RB port change interrupt 0 = Disables the RB port change interrupt</p> <p>bit 2: TOIF: TMR0 Overflow Interrupt Flag bit 1 = TMR0 register has overflowed (must be cleared in software) 0 = TMR0 register did not overflow</p> <p>bit 1: INTF: RB0/INT External Interrupt Flag bit 1 = The RB0/INT external interrupt occurred (must be cleared in software) 0 = The RB0/INT external interrupt did not occur</p> <p>bit 0: RBIF: RB Port Change Interrupt Flag bit 1 = At least one of the RB7:RB4 pins changed state (must be cleared in software) 0 = None of the RB7:RB4 pins have changed state</p>							

R = Readable bit
W = Writable bit
U = Unimplemented bit,
read as '0'
- n= Value at POR reset

PIC16F87X

2.2.2.4 PIE1 REGISTER

The PIE1 register contains the individual enable bits for the peripheral interrupts.

Note: Bit PEIE (INTCON<6>) must be set to enable any peripheral interrupt.

REGISTER 2-4: PIE1 REGISTER (ADDRESS 8Ch)

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
PSPIE ⁽¹⁾	ADIE	RCIE	TXIE	SSPIE	CCP1IE	TMR2IE	TMR1IE
bit7							bit0

R = Readable bit
W = Writable bit
U = Unimplemented bit, read as '0'
- n= Value at POR reset

bit 7: **PSPIE⁽¹⁾**: Parallel Slave Port Read/Write Interrupt Enable bit
1 = Enables the PSP read/write interrupt
0 = Disables the PSP read/write interrupt

bit 6: **ADIE**: A/D Converter Interrupt Enable bit
1 = Enables the A/D converter interrupt
0 = Disables the A/D converter interrupt

bit 5: **RCIE**: USART Receive Interrupt Enable bit
1 = Enables the USART receive interrupt
0 = Disables the USART receive interrupt

bit 4: **TXIE**: USART Transmit Interrupt Enable bit
1 = Enables the USART transmit interrupt
0 = Disables the USART transmit interrupt

bit 3: **SSPIE**: Synchronous Serial Port Interrupt Enable bit
1 = Enables the SSP interrupt
0 = Disables the SSP interrupt

bit 2: **CCP1IE**: CCP1 Interrupt Enable bit
1 = Enables the CCP1 interrupt
0 = Disables the CCP1 interrupt

bit 1: **TMR2IE**: TMR2 to PR2 Match Interrupt Enable bit
1 = Enables the TMR2 to PR2 match interrupt
0 = Disables the TMR2 to PR2 match interrupt

bit 0: **TMR1IE**: TMR1 Overflow Interrupt Enable bit
1 = Enables the TMR1 overflow interrupt
0 = Disables the TMR1 overflow interrupt

Note 1: PSPIE is reserved on 28-pin devices; always maintain this bit clear.


PIC16F87X

RETFIE Return from Interrupt

Syntax: [*label*] RETFIE
 Operands: None
 Operation: TOS → PC,
 1 → GIE
 Status Affected: None

RLF Rotate Left f through Carry

Syntax: [*label*] RLF f,d
 Operands: $0 \leq f \leq 127$
 $d \in [0,1]$
 Operation: See description below
 Status Affected: C
 Description: The contents of register 'f' are rotated one bit to the left through the Carry Flag. If 'd' is 0, the result is placed in the W register. If 'd' is 1, the result is stored back in register 'f'.




RETLW Return with Literal in W

Syntax: [*label*] RETLW k
 Operands: $0 \leq k \leq 255$
 Operation: k → (W);
 TOS → PC
 Status Affected: None
 Description: The W register is loaded with the eight bit literal 'k'. The program counter is loaded from the top of the stack (the return address). This is a two cycle instruction.

RRF Rotate Right f through Carry

Syntax: [*label*] RRF f,d
 Operands: $0 \leq f \leq 127$
 $d \in [0,1]$
 Operation: See description below
 Status Affected: C
 Description: The contents of register 'f' are rotated one bit to the right through the Carry Flag. If 'd' is 0, the result is placed in the W register. If 'd' is 1, the result is placed back in register 'f'.



RETURN Return from Subroutine

Syntax: [*label*] RETURN
 Operands: None
 Operation: TOS → PC
 Status Affected: None
 Description: Return from subroutine. The stack is POPed and the top of the stack (TOS) is loaded into the program counter. This is a two cycle instruction.

SLEEP

Syntax: [*label*] SLEEP
 Operands: None
 Operation: 00h → WDT,
 0 → WDT prescaler,
 1 → \overline{TO} ,
 0 → \overline{PD}
 Status Affected: \overline{TO} , \overline{PD}
 Description: The power-down status bit, \overline{PD} is cleared. Time-out status bit, \overline{TO} is set. Watchdog Timer and its prescaler are cleared. The processor is put into SLEEP mode with the oscillator stopped.

5.0 TIMER0 MODULE

- 8-bit timer/counter
- Readable and writable
- 8-bit software programmable prescaler
- Internal or external clock select
- Interrupt on overflow from FFh to 00h
- Edge select for external clock

Additional information on the Timer0 module is available in the PICmicro™ Mid-Range MCU Family Reference Manual (DS33023).

Counter mode is selected by setting bit T0CS (OPTION_REG<5>). In counter mode, Timer0 will increment either on every rising or falling edge of pin RA4/T0CKI. The incrementing edge is determined by the Timer0 Source Edge Select bit T0SE (OPTION_REG<4>). Clearing bit T0SE selects the rising edge. Restrictions on the external clock input are discussed in detail in Section 5.2.

5.1 Timer0 Interrupt

The TMR0 interrupt is generated when the TMR0 register overflows from FFh to 00h. This overflow sets bit T0IF (INTCON<2>). The interrupt can be masked by clearing bit T0IE (INTCON<5>). Bit T0IF must be cleared in software by the Timer0 module interrupt service routine before re-enabling this interrupt. The TMR0 interrupt cannot awaken the processor from SLEEP since the timer is shut off during SLEEP.

[illegible]

- Initialize timer 0 to overflow about every .0327 seconds.
 - ★ See example on page 100 of Peatman.
- Force interrupt when counter overflows.
- When interrupt occurs, toggle Port C, bit 2.
- Be sure to initialize appropriate registers.

- Goal: Use ports A, B, C, D to exchange data with PLD.
- Port A - four bit address value.
- Port B - four bit data input.
- Port C - up to six control signals.
- Port D - four bit data output.
- Create a four-bit *write* and *read* transaction.
- Transfer should be robust.

- Valid signals indicate when data transfer occurs.
- Four bit *address* followed by *data*.
- For a PIC write, PIC must wait for acknowledge.
- For a PIC read, PLD must wait for data acknowledge.
- Use 4MHz clock for both PIC and PLD.
- Show handshaking signals on logic analyzer.

- Configure port C data direction register.
- *PIC data valid/EPLD data accept* (**PICSTROBE**)
Port C output.
- *PIC data accept/EPLD data valid* (**PLDSTROBE**)
Port C input.
- PIC Read/Write signal (**R/W₋**)
Port C output.
- Could use other encodings.

Inside/Outside the EPLD

- Interface 12 address/data + control signals to PIC.
- One switch input into PLD.
- Four LED outputs from PLD.
- Four bit internal register.
- *Address* and *R/W*₋ used to select destination.

After port A, B, C, D initialization:

1. Send address to Port A.
2. Set R/W_ signal to read.
3. Assert PICREADY signal.
4. Sample PLDREADY to see if PLD has address.
5. When PLDREADY asserted, deassert PICREADY.
6. Wait for PLDREADY deasserted.
7. Repeat previous six steps with *data* on Port D.

After port A, B, C, D initialization:

- Similar address transaction as write.
- Read value *from EPLD* to port B.
- Follow sequential rules.
- Data shouldn't be overwritten.
- Can be simulated with MPSIM

- Implement using VHDL.
- One state machine to check/fetch addresses.
 - ★ check PICREADY.
 - ★ assert/deassert PLDREADY
- One state machine for READ transactions:
 - ★ Decode address.
 - ★ Enable correct location (switches, register)
 - ★ Assert data to Port B.
- One state machine for WRITE transactions:
 - ★ Decode address.
 - ★ Enable correct location (LEDs, register)
 - ★ Read data from Port D to correct location.

- Need to display a string of characters.
- Consider printing string “wow”

```
call    wait           ; subroutine which checks PIR bit 4.
movlw   'w'            ; send ASCII w char. to W
movwf   TXREG          ; send w char. to UART trans. buffer
call    wait           ; subroutine which checks PIR bit 4.
movlw   'o'            ; send ASCII o char. to W
movwf   TXREG          ; send o char. to UART trans. buffer
call    wait           ; subroutine which checks PIR bit 4.
movlw   'w'            ; send ASCII w char. to W
movwf   TXREG          ; send w char. to UART trans. buffer
```

- Approach is clumsy, verbose.

- Before introducing the new approach, consider this code.

```

        ORG 0x0
        goto Start          ; jump to the start of the program

        ORG 0x5
sub1    nop                 ; start of a subroutine
        .
        .
        return              ; return from subroutine

        ORG 0x30
Start   .
        .
        .
        call sub1           ; call the routine
        nop                 ; first instr. after return
    
```

- When *call* is executed the following happens:
 1. PC receives address of *sub1*
 2. top of stack (TOS) receives return addr.

- When *return* is executed the following happens:
 1. PC receives top of stack (TOS), the return address.
- Consider a new instruction *RETLW k*
- When *retlw* is executed the following happens:
 1. PC receives top of stack (TOS), the return address.
 2. The constant value *k* is placed in the W register
- What if the *k* value was a character?

Character String Program

PIC 16F877

```
BANKORAM EQU H'20'           ; equate a constant to hex 20.
    ORG BANKORAM             ; reserve space in DATA MEMORY
    cblock                   ; create a pointer in bank 0 at location 20
    POINTER                  ; name of value
    endc

    ORG 0x0
    goto Start               ; jump to the start of the program

    ORG 0x5
sub1  movf POINTER, W         ; move value in POINTER to W
      addwf PCL, F           ; add value to PC
      retlw A'w'
      retlw A'o
      retlw A'w'
      retlw 0
      RETURN                 ; shouldn't get here

    ORG 0x30
Start clrf POINTER
Loop  call sub1
      .                      ; check if return value is 0
      btfsc status, z        ; branch if not 0
      goto Done              ; else done
      .                      ; check bit 4 in PIR
      movwf TXREG
      .                      ; increment POINTER
      goto Loop              ; print another character

    ORG 0x60
Done  nop
      goto Done
```

- Possible to replace numerous *RETLW* instructions with *dt* directive.

```
Bank0 MACRO ; macro to select bank 0
bcf STATUS, RP0
bcf STATUS, RP1
ENDM
```

- Make 16F877 macros for read/write transactions.
- Macros are *expanded* by assembler.
- Later changes can be confined to macro.

- Rewire lab kit for lab two (PLD, clock)
- Implement using VHDL.
- Demonstrate using logic analyzer.
- Implement serial interface using constant strings.
- Implement timer 0 interrupt and LED toggle.

- Check write transaction first.
- Look at signals on analyzer.
- Debug read transaction.
- Get interrupts with timer working.
- Get constant string code working.
- Demonstrate working system.

- Peatman - chapter 5
- Peatman - pages 100-103
- Peatman - section 8.7 (skim)
- 16F877 data sheet - pages 46-49
- 16F877 data sheet - pages 131-133
- 16F877 data sheet - pages 20-21
- Altera 7032 data sheet

- Display constant strings using directive *dt*.
- Program counter to toggle LED with interrupts.
- Implement bus transaction with PLD.
- VHDL state machines in PLD to handle data transfer.
- Logic analyzer usage.