



Updated: 23 October 2017 Print version

# CEE 577: Surface Water Quality Modeling

Lecture #14  
Gas Transfer & Reaeration  
(Chapra, L20 & L21)

David Reckhow CEE 577 #14 1





## Gas Transfer: Equilibria

### Henry's Law

$$C_A = K_H p_A$$

where,

$C_A$  = concentration of species A at equilibrium, [mol/L or mg/L]

$K_H$  = Henry's Law constant for species A, [mol/L-atm or mg/L-atm]

$p_A$  = partial pressure gas A exerts on the liquid, [atm]

## Gas Transfer: kinetics

- For a typical water system, the change in concentration of the gas with time can be expressed as:

where, 
$$\frac{dC}{dt} = -k_L a (C_s - C_t)$$


- $k_L a$  = gas transfer coefficient, [time<sup>-1</sup>]  
 $C_t$  = concentration at time t, [mol/L or mg/L]  
 $C_s$  = saturation concentration from Henry's Law.

- $k_L a$  is actually the gas transfer coefficient  $k_L$  times the specific surface area,  $a$ , where  $a$  is the bubble surface area divided by the bubble volume. It is quite difficult to determine the two parameters separately. Since they are normally used together a separate determination is not necessary.

## Analyzing Gas Transfer Data

The above equation can be separated and integrated from  $C = C_o$  at  $t = 0$  to  $C = C_t$  at  $t = t$ , yielding:

$$\ln \frac{(C_s - C_t)}{(C_s - C_o)} = -k_L a t$$



- [To next lecture](#)

David Reckhow CEE 577 #14 8