

## Ground Water and Wells

Basic (Geo)Science for Sustainable a Future

Dr. David Boutt


UMass-Amherst, Geosciences Department





Your tasked with locating properties/land to purchase for a high yield (1000 gpm) well for the town of Sunderland, MA and Lakeside, NE on this map. Where would you put it and why? Choose 2 locations.

## What Factors are Important?

- Water Quantity
  - Geology/Hydrology Determines this
  - Impacts on Environment
  - Safe and Sustainable Yields
- Water Quality
  - Natural Water Chemistry
  - Filtration
  - Treatment
- Economic
  - Cost of getting water to users
  - Delivery and Distribution






## Porosity and Permeability

- **Porosity:** Percent of volume that is void space.

- **Sediment:** Determined by how tightly packed and how clean (silt and clay), (usually between 20 and 40%)


- **Rock:** Determined by size and number of fractures (most often very low, <5%)



## Porosity and Permeability

- **Permeability:** Ease with which water will flow through a porous material

- **Sediment:** Proportional to sediment size
  - Gravel → Excellent
  - Sand → Good
  - Silt → Moderate
  - Clay → Poor
- **Rock:** Proportional to fracture size and number. Can be good to excellent (even with low porosity)



# Porosity and Permeability

- Permeability is **not proportional** to porosity.





Table 13.1


Sediment	Porosity (%)	Permeability
Gravel	25 to 40	excellent
Sand (clean)	30 to 50	good to excellent
Silt	35 to 50	moderate
Clay	35 to 80	poor
Glacial till	10 to 20	poor to moderate

# Some ground water basics ...




## Natural Water Table Fluctuations

- Infiltration
  - Recharges ground water
  - Raises water table
  - Provides water to springs, streams and wells
- Reduction of infiltration causes water table to drop





## Natural Water Table Fluctuations

- Reduction of infiltration causes water table to drop
  - Wells go dry
  - Springs go dry
  - Discharge of rivers drops
- Artificial causes
  - Pavement
  - Drainage



## Effects of Pumping Wells


- Pumping wells
  - Accelerates flow near well
  - May reverse ground-water flow
  - Causes water table drawdown
  - Forms a cone of depression




B

## Effects of Pumping Wells

- Pumping wells
  - Accelerate flow
  - Reverse flow
  - Cause water table drawdown
  - Form cones of depression



A





B

## Effects of Pumping Wells

### Continued water-table drawdown


- May dry up springs and wells
- May reverse flow of rivers (and may contaminate aquifer)
- May dry up rivers and wetlands






## Groundwater exploration & exploitation











## DRILLED WELLS

- Casing material: Steel or PVC plastic
- Installed by well drilling contractors
- Much more common than driven or dug wells
- Most are >50 ft. deep (avg. 125 ft.)
- ***MOST SANITARY WELL TYPE***

# WATER WELL DESIGN




- ❖ Provide well that meets needs of owner
- ❖ Obtain highest yield with minimal drawdown (consistent w/ aquifer capabilities)
- ❖ Provide suitable quality water (potable and turbidity-free for drinking water wells)
- ❖ Provide long service life (25+ years)


*NEW: Minimize impacts on neighboring wells & aquatic environments*

## WATER WELL DRILLING METHODS

**MOST COMMON:**



**LESS COMMON:**





### EMERGING TECHNOLOGY

DUAL TUBE ROTARY

HORIZONTAL

SONIC



### TOP HEAD DRIVE ROTARY

TOP HEAD  
DRIVE UNIT

DERRICK  
OR MAST

DRILLING MUD  
RETURN FLOW  
HOSE

DRILL RODS



### DRILLING RIG OPERATOR CHECKING DRILL CUTTINGS

STRAINER

DRILLING  
FLUID  
EXITING  
BOREHOLE

DRILLING MUD TANK




## DRILLER COMPLETING THE WATER WELL RECORD



**WATER WELL & PUMP RECORD DESCRIBES:**

- WELL DEPTH**
- CASING LENGTH**
- GEOLOGIC MATERIALS PENETRATED**
- STATIC WATER LEVEL**
- PUMPING WATER LEVEL**
- PUMPING RATE**
- GROUTING MATERIALS**
- WELL LOCATION**
- PUMPING EQUIPMENT**
- DRILLERS NAME**
- DRILLING RIG OPERATOR**

## TYPICAL ROTARY WELL CONSTRUCTION SEQUENCE




## Bentonite Drilling Fluid - *Functions* -

- REMOVAL OF DRILL CUTTINGS FROM BOREHOLE
- STABILIZE THE BOREHOLE
- COOL AND LUBRICATE DRILL BIT
- CONTROL FLUID LOSS TO GEOLOGIC FORMATIONS
- DROP DRILL CUTTINGS INTO MUD PIT
- FACILITATE COLLECTION OF GEOLOGIC DATA
- SUSPEND CUTTINGS WHEN DRILLING FLUID CIRCULATION STOPS



**Temporary well cap -  
installed between  
well drilling and  
pump hook-up**











**This drilled well has an older style well cap that does not seal tightly to the well casing.**



**Insects and small animals can enter the well and contaminate the drinking water.**

**Caps of this design are not acceptable and should be replaced.**












Table 9.1 Reactivity of Steel Casing to Corrosive Waters

Reactive Agent	Water Quality	Reaction
pH	less than 5.5	corrosive
O <sub>2</sub>	more than 4 mg/L	corrosive
CO <sub>2</sub>	more than 100 mg/L	corrosive
CO <sub>2</sub>	50 to 100 mg/L	marginal/corrosive
CO <sub>2</sub>	less than 50 mg/L	acceptable

### Sintered HDPE Screens





### PVC Screens




Table 9.2 Comparison of Strengths of Bore Casing Materials

Material	Specific Gravity	Tensile Strength 10 <sup>3</sup> kPa	Tensile Modulus 10 <sup>3</sup> kPa	Impact Strength (3)	Upper Temp. Limits, °C
ABS	1.04	31	20.0	6.0	50
PVC	1.40	55	28.0	1.0	40
Fibreglass	1.89	115	158.0	20.0	80
FRP					(4)
Steel	7.85	240 (yield) 410 (ultimate)	2 068.0	(2)	800 - 1000
Stainless Steel	8.0	240 (yield) 550 (ultimate)	2 000.0	(2)	800 - 1000

(1) Yield strength is the tensile stress required to produce a total elongation of 0.5 percent of the gauge length as determined by an extensometer. Expressed in psi.  
 (2) The impact strength of steel is so high relative to the demands of water well work that it can be ignored in design considerations.  
 (3) Relative to PVC.  
 (4) FRP higher temperature with special resins.






## BENEFITS OF WELL GROUTING

- *PREVENT CONTAMINANT MIGRATION FROM SURFACE (Keeps surface runoff from moving downward along well casing)*
- *SEAL OFF POOR QUALITY AQUIFERS (Prevents mixing of water from different aquifers)*
- *PRESERVE ARTESIAN AQUIFER PROPERTIES*
- *ADDED SEALING OF CASING JOINTS*





**Bore Development**

Drilling fluid invasion

Borehole

Well screen

Sand bridges

Well screen

Rubber flap


Pipe

Pressure-relief hole

Rubber disc

Steel or wooden disc

The complex block contains four images. Top left: A cross-section showing drilling fluid invasion into a borehole. Top right: A diagram showing sand bridges forming between well screens. Bottom left: A technical drawing of a well screen assembly with labels for rubber flap, pipe, pressure-relief hole, rubber disc, and steel or wooden disc. Bottom right: A photograph of a well screen installed in a borehole, surrounded by gravel.



## **DUG WELLS**

- **Large diameter (18-48 in.)**
- **Found in low yield areas**
- **Casing material - concrete crocks w/ loose joints**
  - **Older wells: stones, brick-lined**
- **Water enters well through loose casing joints**



## **DUG WELLS**

- Older wells - hand dug
- Now installed (on very limited basis) w/ bucket augers (backhoes – phased out)
- Low well yield - storage in casing (100's of gallons)
- **HIGHLY VULNERABLE TO CONTAMINATION**

## **CDC Findings on Dug Wells**

- Dug/bored wells had a positive coliform bacteria rate of about 85%
- Wells with brick, concrete or wood casing (dug wells) had coliform positive rates of 60 – 90 %

*From A Survey of the Presence of Contaminants in Water From Private Wells in Nine Midwestern States, Atlanta, Georgia, U.S. Dept. of Health and Human Services, Public Health Service, Centers for Disease Control, 1996*





A cross-sectional diagram of a pumping well. The well is shown as a vertical pipe with a screen at the bottom. The water level inside the well is labeled 'Pumping water level'. The surrounding ground water level is labeled 'Static water level'. The area of water being drawn into the well is labeled 'Cone of Depression'.

A cross-sectional diagram of a well. The top is labeled 'Land surface'. Below it is the 'Static water level'. The vertical distance from the static level to the 'Pumping level' (where the 'Well screen' is located) is labeled 'Depth to water'. The area of water being drawn into the well is labeled 'Cone of depression'. The vertical distance from the static level to the pumping level is labeled 'Drawdown'. The horizontal distance from the well to the edge of the cone of depression is labeled 'Radius of influence'.

Some useful terms to know:

- ✓ Cone of depression
- ✓ Drawdown
- ✓ Radius of influence
- ✓ Specific capacity

A cross-sectional diagram of a well. The top is labeled 'well yield'. Below it is the 'static water level'. The area of water being drawn into the well is labeled 'cone of depression'. The vertical distance from the static level to the 'water level due to pumping' is labeled 'drawdown'. The vertical distance from the static level to the 'well screen' is labeled 'specific capacity = well yield / drawdown'. The bottom layer is labeled 'aquitard'.



## Zone 2 Groundwater Protection Area

- **Zone II:** That area of an aquifer which contributes water to a well under the most severe pumping and recharge conditions that can be realistically anticipated (180 days of pumping at approved yield, with no recharge from precipitation). It is bounded by the **groundwater divides which result from pumping the well and by the contact of the aquifer with less permeable materials such as till or bedrock**. In some cases, streams or lakes may act as recharge boundaries. In all cases, Zone II shall extend upgradient to its point of intersection with prevailing hydrogeologic boundaries (a groundwater flow divide, a contact with till or bedrock, or a recharge boundary).

## SAFE YIELD

Two Factors Govern Groundwater Supply Capacity

**Well Yield** - the maximum rate at which a well can be pumped without causing water levels to be drawn below the level of the pump and uppermost water-bearing zone.

**Sustainable Aquifer Capacity** - the maximum rate at which the aquifer can transmit water to the well sustainably with long-term pumping.

## Factors Influencing Safe Yield


### Average Annual Precipitation

- Watershed Area
- Recharge Rate
- Presence of Surface Water Bodies
- Aquifer Parameters (transmissivity, storativity)
- Competing Water Demands

Knowledge of these variables, combined with a well-formulated conceptual model, can support an initial estimate of likely **Safe Yield** of a well.

### 180-DAY PROJECTION OF WATER LEVEL TREND

End-of-Test Drawdown trend projected to a period of 180 days (259,200 minutes). Projected water level is 23.5 feet below sea level, assuming no boundaries. Top of water-bearing zone in this gravel-pack well is around 10 feet below sea level, so we would expect trend to steepen as aquifer is gradually dewatered and saturated thickness decreases. Unless some source of recharge is nearby, the yield of 64.8 gpm is probably not sustainable. Data from Antigua.



180-Day Projection with No Recharge: Pumping Well Greencastle 5



## EXTRAS

### Why Pumping Tests?

1. Establish the **Safe Yield** of well
2. Calculate **Aquifer Parameters** – K, T, S, Sc etc.
3. Obtain representative **Water Quality** samples
4. Determine well's **Recovery Characteristics**
5. Select **Pumps** and Pumping Schedules
6. Estimate **Zone of Capture (ZOC) & Wellhead Protection Area(WPA)**
7. **Determine effects**, if any, on other nearby **Wells, Wetlands**, etc.
8. **Determine** if suspected **Contaminant Threats** are a problem

## Types of Pump Tests

### Step Test

- Performed two or more days prior to the start of constant rate tests (allow for complete water level recovery to occur prior to start up of Constant Rate Test )
- Test usually includes from three to eight equal time pumping steps of from 90-120 minutes duration while incrementally increasing the discharge rate after each Step and keeping discharge rate constant during each step.
- Very important to measure drawdown frequently for bedrock wells to determine fracture dewatering depth ( or install recording pressure transducer)
- May be the only real opportunity to overstress the well before putting on-line
- Analyze step test data and conduct step tests using formation and fracture location data


### Constant Rate Test

- Pumping rate fixed for duration of test – Testing continues for several days until the well water levels have reached complete stabilization or log stabilization
- Aquifer water levels, barometric pressure, rainfall and ambient monitoring well data collected prior to, during and after pumping for specified period of time.

## Pumping Test Set up-Trinidad



### V-Notch Weir and Orifice Weir



**Orifice Weir** - Measures rate of flow using Pitot tube – pressure increases as flow increases

**Rain Gauge** - Collects rainwater to account for recharge during the test

**Magnetic Flowmeter** - Measures rate of flow of water through the pipe

**Backpressure Gauge** - Measures water pressure against gate valve

**Water Level Probe** – Measures water level drawdown during the test (automatic recording downhole pressure sensing transducers are preferable)

### At Constant-Rate-Pump Test Startup . . . . .

- Prior to start of the test, open the flow (gate) valve to achieve the desired flow for the first step as quickly as possible.
- One person should be monitoring pump discharge while another measures water levels. ( If possible, purchase recording pressure transducers to make life easy)
- During the first few minutes of the test, drawdown may occur rapidly so it is important to check discharge frequently, and also calibrate discharge with a bucket and stopwatch.

If manually taking measurements use the following minimum recording schedule.

- First minute - at 30 and 60 seconds
- 1- 10 minutes - every minute
- 10 - 30 minutes - every 2 to 4 minutes
- 30 - 60 minutes - every 5 to 10 minutes
- After 60 minutes - every hour for first 24 hours
- For remainder of test period – 4 to 8 times per day

More frequently at end of test period ...OR....Set Automatic reading transducers to record at 10 minute intervals throughout the remainder of the test period)

## ZEROING IN ON SAFE YIELD

**What if the pumping rate used for the constant rate test produces a 180-day water level projection that is too deep, or too shallow?**


Two key aquifer parameters, transmissivity and storativity, can be calculated using test data.

Parameter calculations are made using "analytical methods" (e.g., Theis or Jacob).


Same methods are then used to back-calculate the precise pumping rate corresponding with maximum allowable drawdown amount.



For hydrogeologically complex settings, or those involving higher-capacity water supplies, numerical flow models are frequently used to obtain more accurate and dependable assessments of safe yield.

**600 US gpm Constant Rate Data**  
Water Level vs. Time



**Fractured Bedrock Well- Constant Rate Test -255 GPM**  
Round Hill, VA – circa 1985





### **CAN YOU TRUST THE TREND?**

**Using the prevailing end-of-test water level trend to project the 180-day water level carries the assumption that the trend would persist unchanged if pumping continued. A good assumption? Possibly, but with Exceptions**

#### **1. RECHARGE BOUNDARY ENCOUNTERED BEFORE END OF TEST**

If drawdown "stops" before the end of the test, and the final trend of the water level data is horizontal, the cone of depression has expanded far enough to encounter a recharge boundary with recharge sufficient to exactly balance the withdrawal rate.

If the stabilized water level is far enough above the pump and highest water-bearing zones to give the desired margin of safety, the pumping rate is sustainable.




### **CAN YOU TRUST THE TREND?**

#### **2. RECHARGE BOUNDARY *NOT* ENCOUNTERED BEFORE END OF TEST**

If the end-of-test water level trend is a decline, possibility remains that one or more boundaries would have been encountered if pumping continued-- either recharge (producing shallower rate of decline or water level stabilization) or barrier (producing steepening of water level decline, and more rapid-than-expected consumption of available drawdown).

There's nothing in the pumping test data to predict when the next boundary might be encountered, so we fall back on what the conceptual model can tell us, and we err on the side of conservatism in estimating the well's safe yield to account for the added uncertainty.

# Aquifer Management





## Technical Base to Groundwater Management

- Identification of the recharge and discharge areas and connectivity of the aquifer system
- Characterization of hydrogeologic properties of aquifers, water quality, hydraulic heads and flow of groundwater
- Development of mathematical models of hydrogeologic behavior and risk analysis (vulnerability on local and regional scale)
- A network and information system that integrates groundwater data base (quantity and quality parameters, well characteristics, use and protection)